a.Download firmware upgrade tool

Windows OS:

https://www.dropbox.com/s/zwkt6y9svklpkyl/Pantum%20P2200-P2500%20Series%20Windows%20FirmwareUpgrade%20Tool%20V1.0.zip?dl=0

MAC OS:

https://www.dropbox.com/s/fcny4nhc51bpsop/Pantum%20P2200-P2500%20Series%20MAC%20FirmwareUpgrade%20Tool%20V1.0.rar?dl=0

b.Update firmware, follow these steps:

a) turn on the printer

b) use a USB cable connect the printer and computer

c) click "start" button

Notice: During the upgrade, please do not carry out any operation on the printer and computer.

Pantum Firmware Upgrade Tool(FW1.x.5.5)

```
Tips:
1. This upgrade tool can only support being connected to
one Pantum printer for upgrade at a time.
2. The printer series supported by this version of
upgrade tool:
Pantum P2200 series
Pantum P2200W series
Pantum P2500N series
Pantum P2500W series
Pantum P2500NW series
Pantum P2550 series
Pantum S2000 series
```

Notice: Please do not turn off the printer and the computer during the upgrade.

The upgrade steps are as follows:

1. Please turn on the printer, and set it to the ready or sleep state;
2. Use a USB cable to connect the printer and the computer;
3. Click the "Start to upgrade" button.

[Start to upgrade]

Pantum Firmware Upgrade Tool(FW1.x.5.5)

The data is being transmitted, please wait···

d)Press "cancel/continue" button to confirm the update on the printer

Pantum Firmware Upgrade Tool(FW1.x.5.5)

The printer is ready for upgrade, please reconfirm on the printer:

1. Press the "cancel / continue" button to confirm the upgrade;

2. Press and hold the "cancel / continue" button for more than 2s to cancel the upgrade task.

Pantum Firmware Upgrade Tool(FW1.x.5.5)

The firmware is upgrading, please wait…

Notice: During the upgrade, please do not carry out any
operation on the printer and computer.

Pantum Firmware Upgrade Tool(FW1.x.5.5)

The firmware upgrade is successful.

The printer shall be used with the new driver after the firmware upgrade, please check the operation guide for upgrade tools.

Complete

C. Install printer driver ,

a) Run CD to set up driver

b) Select "Enter SSID Manually"

Pantum P2200-P2500-P2600 Series   ✕

PANTUM

You can click Print Wireless Network Information Page to print the list of wireless networks detected by the printer.

Service Set Identifier (SSID):

[   ]

☑ Enter SSID Manually

[Print Wireless Network Information Page]   [Next]   [Cancel]

c) Input wireless name,click Next

Pantum P2200-P2500-P2600 Series ✕

PANTUM

You can click Print Wireless Network Information Page to print the list of wireless networks detected by the printer.

Service Set Identifier (SSID):

Shopper+network

☑ Enter SSID Manually

Print Wireless Network Information Page   Next   Cancel

d) 1) Safe Mode: Select « WPA/WPA2 »
    2) Input Password
    3) Click Next

e) Click Done